

# Installing Freedom Wings



Using a sharpie, align the freedom wing with the side of the fairing and mark two holes.



Take the reinforcement piece and place inside fairing along the inside edge.





Using a 1/16 drill bit, drill through the fairing and through the reinforcement piece.



Remove the reinforcement piece from inside the fairing and apply 2-part epoxy to the edge being attached to the inside of the fairing.





Place the reinforced piece back inside the fairing and attach with the two screws supplied.



After 20 minutes, depending on the weather (cooler temps may take longer to dry), back the screws out and attach the brackets of the freedom wings to the reinforced piece using the same two screws.









The finished product!











